



PHWS

OPERATOR'S MANUAL

■ PHWS3-1100

■ PHWS4-2000

■ PHWS4-3000

■ PHWS5-3000



For technical assistance or the Landa Dealer nearest you, consult our web page at www.landa.com or call 800-LANDA-4-U (800-526-3248) or (360) 833-9100

CONTENTS

Introduction	4
Unpacking	4
Important Safety Information	4-5,7
Component Identification	6
Pre-Operation Check	7
Set Up Procedures	7
Operating Instructions	7
Shut Down Procedures	7
General Washing Techniques	7-8
Steam Combination	8
Preventative Maintenance	8
Maintenance & Service	8-10
Time Delay Shutdown	10
Auto Start/Stop Timer	10
PHWS Exterior View	11
PHWS Control Panel	12
PHWS Control Panel Parts List	13-14
PHWS Valves Exploded View and Parts List	15
PHWS Combustion Assembly and Parts List	16-17
PHWS Chassis and Parts List	18-19
PHWS Pump Assemblies and Parts List	20-21
PHWS Float Tank and Parts List	22
Hose & Spray Gun Assembly and Parts List	23
PHWS Power Platform and Parts List	24-25
Beckett Burner Specifications	26
Wayne Burner Specifications	27
Pump Parts Specifications	28-29
Troubleshooting	30-35
Preventative Maintenance	36
Oil Change Record	36
Warranty	37
Spanish Translations	38-42

Model Number _____

Serial Number _____

Date of Purchase _____

The model and serial numbers will be found on a decal attached to the pressure washer. You should record both serial number and date of purchase and keep in a safe place for future reference.

INTRODUCTION

Thank you for purchasing a Landa Pressure Washer.

This manual covers the operation and maintenance of the PHWS3-11021D, PHWS4-20021A, PHWS4-20021B, PHWS4-20021C, PHWS4-20021G, PHWS4-20021H, PHWS4-30021A, PHWS4-30021B, PHWS4-30021C, PHWS4-30021F, PHWS4-30021H, PHWS4-30021G, PHWS5-30021B, PHWS5-30021C, PHWS5-30021F, PHWS5-30021H, PHWS3-11024D, PHWS4-20024A, PHWS4-20024B, PHWS4-20024C, PHWS4-20024F, PHWS4-20024G, PHWS4-20024H, PHWS4-30024A, PHWS4-30024B, PHWS4-30024C, PHWS4-30024F, PHWS4-30024G, PHWS4-30024H, PHWS4-30024N, PHWS5-30024B, PHWS5-30024C, PHWS5-30024F, PHWS5-30024G, PHWS5-30024H and PHWS5-30024N washers. All information in this manual is based on the latest product information available at the time of printing.

Landa, Inc. reserves the right to make changes at any time without incurring any obligation.

The PHWS Series was designed for maximum use of 8 hours per day, 5 days per week.

Owner/User Responsibility:

The owner and/or user must have an understanding of the manufacturer's operating instructions and warnings before using this Landa pressure washer. Warning information should be emphasized and understood. If the operator is not fluent in English, the manufacturer's instructions and warnings shall be read to and discussed with the operator in the operator's native language by the purchaser/owner, making sure that the operator comprehends its contents.

Owner and/or user must study and maintain for future reference the manufacturers' instructions.

This manual should be considered a permanent part of the machine and should remain with it if machine is resold.


When ordering parts, please specify model and serial number.

UNPACKING

Carefully unpack your new LANDA washer and check contents against packing slip. Basic equipment with each machine includes:

1. Pressure washer assembly
2. High pressure discharge hose
3. Wand assembly
4. Spray gun on machines where applicable
5. Operator's manual

IMPORTANT SAFETY INFORMATION



CAUTION: To reduce the risk of injury, read operating instructions carefully before using.

1. Read owner's manual thoroughly. Failure to follow instructions could cause malfunction of the machine and result in death, serious bodily injury and/or property damage.
2. Know how to stop the product and bleed pressures quickly. Be thoroughly familiar with the controls.
3. Stay alert - watch what you are doing.
4. All installations must comply with local codes. Contact your electrician, plumber, utility company or the selling distributor for specific details. To comply with the National Electrical Code (NFPA 70) and provide additional protection from risk of shock, this product is provided with a ground fault circuit interrupter (GFCI) built into the power cord plug (250V 30 amp or less, 1 PH). If replacement of the plug or cord is needed, use only identical replacement parts.


DANGER: Improper connection of the equipment-grounding conductor can result in a risk of electrocution. Check with a qualified electrician or service personnel if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the product. If it will not fit the outlet, have a proper outlet installed by a qualified electrician.



WARNING: Do not use gasoline, crankcase drainings or oil containing gasoline, solvents or alcohol. Doing so will result in fire and/or explosion.

WARNING: Risk of explosion-do not spray flammable liquids.

5. In oil burning models, use only kerosene, No. 1 home heating fuel, or diesel. If diesel is used, add a soot remover to every tankful.



WARNING: Risk of asphyxiation. Use this product only in a well ventilated area.

6. Avoid installing machines in small areas or near exhaust fans. Adequate oxygen is needed for combustion or dangerous carbon monoxide will result.



WARNING: Risk of fire. Do not add fuel when machine is operating or still hot.

- Turn machine off before refueling. Fire and/or explosion may occur if this is not done. Refuel in a well ventilated area.



WARNING: Keep water spray away from electrical wiring or fatal electrical shock may result. Read warning tag on electrical cord.

- To protect the operator from electrical shock, the machine must be electrically grounded. It is the responsibility of the owner to connect this machine

to a UL grounded receptacle of proper voltage and amperage ratings. Do not spray water on or near electrical components. Do not touch machine with wet hands or while standing in water. Always disconnect power before servicing.

CAUTION: Spray gun kicks back — hold with both hands.

- Grip cleaning wand securely with both hands before starting the cleaner. Failure to do this could result in injury from a whipping wand.



WARNING: Flammable liquids can create fumes which can ignite causing property damage or severe injury.

- Oil burning appliances shall be installed only in locations where combustible dusts and flammable gases or vapors are not present. Do not store or use gasoline near this machine.



WARNING: Risk of injection or severe injury to persons. Keep clear of nozzle. Do not touch or direct discharge stream at persons. This machine is to be used only by trained operators.

CAUTION: Hot discharge fluid. Do not touch or direct discharge stream at persons.

- High pressure developed by these machines will cause personal injury or equipment damage. Use caution when operating. Do not direct discharge stream at people, or severe injury or death will result.
- Never make adjustments on machine while it is in operation.




WARNING: High pressure spray can cause paint chips or other particles to become airborne and fly at high speeds.


- Eye safety devices, foot protection and other protective clothing must be worn when using this equipment.

14. The spray gun should not be operated with the trigger in the off position for extensive periods of time as this may cause damage to the pump. Check to make sure burner shuts off with spray gun closed.

- Protect from freezing.
- Protect discharge hose from vehicle traffic and sharp objects.
- To prevent serious injury, be certain quick coupler on discharge hose has locked before using pressure washer.
- Before disconnecting discharge hose from hot water outlet, turn off burner and open spray gun to allow water to cool to 100°, then turn off pump motor and water supply and open spray gun to relieve back pressure in hose. This will prevent coil damage from thermal expansion.
- Do not allow acids, caustic or abrasive fluids to pass through the pump.
- Inlet supply water must be cold and clean fresh water.
- The best insurance against an accident is precaution and knowledge of the machine.
- LANDA will not be liable for any changes made to our standard machines or any components not purchased from LANDA.



COMPONENT IDENTIFICATION
ALL MODELS



23. To reduce the risk of injury, close supervision is necessary when a product is used near children. Do not allow children to operate the pressure washer. **This machine must be attended during operation.**
24. Do not overreach or stand on unstable support. Keep good footing and balance at all times.
25. Follow the maintenance instructions specified in the manual.
26. Do not operate this product when fatigued or under the influence of alcohol or drugs. Keep operating area clear of all persons.

PRE-OPERATION CHECK

- Check pump oil level. (Use SAE 30W non-detergent oil). Dipstick is located on top of pump.
- Cold water supply (minimum 6 gpm, 5/8", 30 psi)
- Hose, wand, nozzle (nozzle size per serial plate)
- Water filter (intact, non restrictive)
- Open spray gun to relieve pressure before starting.

SET-UP PROCEDURES

Machines must be stored indoors when not in use.

- Location of machine is important. Avoid installing near combustible material or in poorly ventilated areas.
- Electrical connection to machine should be the proper voltage, phase and amperage. See specifications for particular model. Plug the power cord into a **grounded receptacle**. The PHWS3-11024D requires a 20 amp receptacle to comply with UL 1776 standards.
- Water source for machines should be supplied by a 5/8" I.D. garden hose with a city water pressure of not less than 30 PSI. If the water supply is inadequate, or if the garden hose is kinked, the machine will run very rough and the burner will not fire.
- Fill fuel tank with proper fuel.
- Adding exhaust vent pipe to your oil fired burner is not recommended because it restricts air flow. This causes carbon build-up, which affects the operation and increases maintenance on the coil. If a stack must be used, refrain from using 90° bends. If the pipe can not go straight up then use only 45° bends and go to the next larger size pipe. The overall pipe length must not exceed 6 feet in length.

OPERATING INSTRUCTIONS

- Read safety, installation and preventative maintenance instructions before starting machine.
- Connect the water supply hose to the float tank inlet swivel connector and turn on water supply.

- Check fuel tank level.
- Connect the high pressure hose quick coupler to discharge nipple by sliding the quick coupler collar back and inserting quick coupler on coupler nipple and pushing the quick coupler collar forward to secure it.
- Connect the wand, nozzle, hose and spray gun (where applicable). Use teflon tape on pipe thread connections to avoid water leaks (see Component Identification).
- Plug the power cord into the proper power supply. (Refer to serial plate for information.)
- Grip spray gun and wand handle securely.
- Press the pump switch "ON" and then pull the trigger on the spray gun to activate pressure switch which starts machine (For auto start machines only).

When a steady stream of water flows from the spray gun and wand, turn the thermostat knob to the 200° mark, then push the burner switch. The burner will light automatically when the spray gun trigger is pulled.

For machines with time delay shut down, simply press pump switch "ON" and the machine will start.

- Turn the variable pressure control handle clockwise to increase pressure.
- Place detergent hose into detergent container and open detergent valve.

SHUT DOWN PROCEDURES

- Place detergent line in a bucket of water allowing detergent to be flushed from system. Then turn detergent valve off.
- Push burner switch off or turn switch to pump position and open trigger on spray gun, allowing water to flow, which will cool down the heating coil.
- After water has cooled, release the trigger on the spray gun which will activate a timer to shut the machine off after one minute. Turn the pump switch off if the machine is going to be left unattended.
- Turn water off.
- Protect from freezing (see Winterizing Procedures).

GENERAL WASHING TECHNIQUES

This machine is equipped with a spray gun and various nozzle patterns, use the wide patterns on easy soil removal jobs and the narrow patterns on the more difficult jobs or tight areas such as cracks and holes.

In most cases, faster results and better detergent economy will be obtained by applying the detergent and letting it "set" for a few minutes, prior to rinsing. This enables it to do its soil penetrating and loosening work.

Most cleaning work terminates with a high pressure rinse as part of the normal cleaning procedure. In some cases, however, the last operation may be the application of a detergent (a sanitizer, for example). After such work, run machine for 20 - 30 seconds to clear the pump and lines.

Do not run anything through this machine that will damage the steel heating coil and pump.

STEAM COMBINATION

- ❑ Turn the chemical valve counterclockwise. (Detergent will not siphon when the steam valve is opened.)
- ❑ Turn the thermostat knob to the 270° mark. (The thermostat is a high limit device and does not regulate temperature).
- ❑ To stop, reverse first 3 steps and set all controls to their original settings.
- ❑ Turn burner switch off, open trigger on spray gun and allow water to cool.

PREVENTATIVE MAINTENANCE

- ❑ Use clean fuel - kerosene, No. 1 home heating fuel or diesel. Clean or replace fuel filter every 100 hours of operation. Avoid water contaminated fuel as it will seize up the fuel pump. De-soot coils monthly or use an additive if diesel is being used.
- ❑ Check to see that water pump is properly lubricated.
- ❑ Follow winterizing procedure to prevent freeze damage to pump and coils.
- ❑ Always flush detergents from system after use.
- ❑ If water is known to be high in mineral content, use a water softener on your water system or use a *LANDA* recognized coil cleaning detergent.
- ❑ Do not allow acidic, caustic or abrasive fluids to be pumped through the system.
- ❑ Always use high grade quality *LANDA* cleaning detergents.
- ❑ Never run pump dry for extended periods of time.
- ❑ Periodically delime coils per instructions.
- ❑ If machine is operated with smoky or eye-burning exhaust, coils will soot up and prevent water from reaching maximum operating temperature. See section on burner adjustments.

MAINTENANCE AND SERVICE

Pump Lubrication:


Use only *LANDA* SAE 30 weight, non-detergent oil. Change oil after first 50 hours of use. Thereafter, change oil every three months or at 500 hour intervals. Oil level

should be checked through use of dipstick found on top of pump or red dot visible through oil gauge window. Oil should be maintained at that level.

Fuel:

Use clean (not contaminated with water and debris) kerosene, No. 1 home heating fuel or diesel. Drain fuel tank and replace fuel filter every 100 hours of operation.

Electrode Setting: Wayne




Top View

Side View

Periodically Check Wiring Connections.
If Necessary To Adjust Electrodes, Use Diagram.


Electrode Setting: Beckett:



Ignition Circuit:

Periodically inspect wires, spring contact and electrodes for condition, security and proper spacing. Transformer test: **CAUTION:** 10,000 volts — use defect free insulated screwdriver and keep fingers off blade! Lay blade across one contact: OK if arc will span 1/2" between end of blade and other contact (see illustration below).

Transformer Check:



Fuel Control System:

These machines utilize a fuel solenoid valve located on the fuel pump to control the flow of fuel to the combustion chamber. This solenoid, which is normally closed, is activated by the flow switch. When an operator releases

the trigger on the spray gun, the unloader goes into a bypass mode, thus stopping electrical current to the fuel solenoid coil. With the solenoid closed, the fuel supply to the combustion chamber ceases. Periodic inspection to insure that the fuel solenoid valve functions properly is recommended. This can be done by operating the machine and checking to see that when the spray gun is in the off position, the burner is not firing.

Fuel Pressure Adjustment:


To adjust fuel pressure, turn the adjusting screw clockwise to increase, counterclockwise to decrease. Do not exceed 200 PSI. **NOTE:** When changing fuel pump, a bypass plug must be installed in return line port or fuel pump will not prime. (See illustration below.)

Burner Nozzle:

Keep tip free of surface deposits by wiping with clean, solvent-saturated cloth, being careful not to plug or enlarge nozzle. For maximum efficiency, replace nozzle each season.

Air Adjustment:

FUEL AIR ADJUSTMENT



Machines are preset and performance tested at the factory elevation of 100'. A onetime initial correction for your location will pay off in economy, performance and extended service life. If a smoky or eye-burning exhaust is being emitted from the stack, two things should be checked. First, check the fuel to be certain that kerosene or No.1 home heating fuel is being used. Next, check the air adjustment on the burner. An oily, smoky fire indicates a lack of air and the air band should be moved to allow the air to flow through the burner. Sharp eye-burning fumes indicate too much air flowing through the combustion chamber. The air band should be readjusted to allow less air to flow through the burner.

To adjust, start the machine and turn burner ON. Loosen two locking screws found in the air shutter openings (see illustration) and close air shutter until black smoke appears from burner exhaust vent. Note air band position. Next, slowly open the air shutter until white smoke just starts to appear. Turn air shutter halfway back to the black smoke position previously noted. Tighten locking screws. If the desired position cannot be obtained using only the air shutter, lock the air shutter in as close a position as can be obtained, then repeat the above procedure on the air band setting.

Cleaning of Coils:

In alkaline water areas lime deposits can accumulate rapidly inside the coil pipes. This growth is increased by the extreme heat buildup in the coil. In areas where alkaline water is an extreme problem, periodic use of *LANDA* Deliming Powder will remove lime and other deposits before coil becomes plugged.

Deliming Coils:

Periodic flushing of coils is recommended.

1. Fill the float tank with 4 gallons of water, then add 1 lb. of deliming powder. Mix thoroughly.
2. Remove nozzle from wand assembly and put spray gun and wand assembly into float tank. Attach a nylon stocking to the end of the wand to collect debris.
3. Turn pump switch on, allowing solution to be pumped through coils and back into the float tank. Solution should be allowed to circulate 2 - 4 hours.
4. After circulating solution, clean and drain float tank and flush entire system with fresh water. Replace nozzle in wand.

Spray Nozzles:

Each machine is equipped with four spray nozzles. Different spray nozzles are calibrated for each machine depending on the flow and pressure of that particular model. Spray nozzles vary in bore size and angle of spray. Popular spray angles are 0°, 15°, 25° and 40°. When ordering, please specify size and angle of nozzle. Nozzle size for each machine is located on the serial plate.

Unloader Valves:

Unloader valves are preset and tested at the factory before shipping. Occasional adjustment of unloader may be necessary to maintain correct pressure. (Consult your local *LANDA* Dealer for the correct procedures.)

Winterizing Procedure:

Damage due to freezing is not covered by warranty. Adhere to the following cold weather procedures whenever the washer must be stored or operated outdoors under freezing conditions.

During the winter months, when temperatures drop below 32° F, protecting your machine against freezing is necessary. Siphoning a small amount of antifreeze into the system is recommended. Pouring a 50/50 mix of antifreeze and water into the float tank and then siphon 100% antifreeze through the detergent line with the pump on. If compressed air is available, an air fitting can be screwed into the float tank strainer fitting and, by injecting compressed air, all water will be blown out of the system.

Low Pressure Diagnosis:

Refer to the low pressure section of the troubleshooting guide. If, by referring to the guide, the trouble is found to be either the unloader or pump, your next step is to determine which is the problem. This can be done by eliminating the unloader from the system and attaching the discharge hose directly to the pump. If high pressure is present, then the unloader needs repairing or replacing.

CAUTION: When using this procedure to test components, keep spray gun open at all times.

Coil Removal:

Removal of the coil because of freeze breakage or to clean soot from it, can be done quickly and easily.

1. Disconnect hose from pump/unloader to inlet side of coil.
2. Disconnect the electrical connections to the thermostat or remove thermostat sensor.
3. Remove all the fittings from the discharge and inlet side of the coil.
4. Remove burner assembly from combustion chamber.
5. Remove 3 - 3/8" bolts from either side of coil and tank assembly (these bolts are used to fasten tank and handles to chassis).
6. Remove the two 3/8" nuts which are underneath the bottom wrap (to keep the coil from moving).
7. Remove tank top wrap exposing insulation and coil. Carefully bend insulation tabs at exhaust stack.
8. Carefully fold back insulation and remove the coil.
9. Replace or repair any insulation found to be torn or broken.
10. Reinstall new or cleaned coil by reversing steps 8 through 1.

Temperature and Pressure Relief Valve:

(Pump Protector)

Machines with spray gun control offer the operator the convenience of stopping and starting the flow of water at the end of the discharge hose. When the spray gun stops the flow of water, the unloader valve, back at the machine, opens and recycles the cold water back to the inlet side of the pump. Recycling for longer than five min-

utes causes the cold water within the pump to heat up. To avoid damage to the pump, a temperature and pressure relief valve is installed next to the inlet side of the pump that will open in the event the water temperature exceeds 140° F. Therefore, while operating the machine, do not leave the spray gun closed for an extended period of time.

High Limit Hot Water Thermostat:

For safety, PHWS machines are equipped with adjustable thermostats. If the temperature of the water should exceed its operating temperature, the high limit snap switch or adjustable thermostat will turn the burner off until the water cools, then it will automatically reset itself.

Rupture Disk:

If pressure from pump or thermal expansion should exceed safe limits, the rupture disk will burst, allowing high pressure to be discharged through hose to ground. When the disk ruptures, it will need to be replaced. Torque replacement disk to 35 lbs.

TIME DELAY SHUTDOWN OPERATION

Once the spray gun trigger is released, the shutdown timer becomes activated. The machine will continue to run in by-pass mode until the timer reaches its preset time, 1 - 10 minutes. When that time is reached, the machine shuts down. To restart, push the pump switch forward.


AUTO START/STOP TIMER OPERATION OPTION

Once the pump switch is turned on, simply triggering the spray gun is all it takes to start the machine. Once the trigger is released the timer will let the machine bypass water for 15 seconds. It also starts an internal 5 to 60 minute lockout timer. This feature is totally adjustable by the operator by adjusting the knob at the top of the timer. We recommend setting the timer for 15 minutes. To reset the lockout feature, operator must trigger the spray for 10 full seconds.


4-3000A Motor E-Box Mounting Instr.

- 1: Remove capacitor cover and capacitor.
- 2: Drill two holes in junction box to mount to motor.
- 3: Apply silicone to the top of motor around hole and to each screw.
- 4: Attach box with screws(90-19711).
- 5: Apply silicone to two screws from the motor and screw into motor.

PHWS EXTERIOR VIEW
ALL MODELS



PHWS CONTROL PANEL
ALL MODELS



**PHWS CONTROL PANEL
ALL MODELS PARTS LIST**


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1		Contactora, See Pages 26-27	1	30	6-03621	Relay, 120V RHZB-U1-AC120	1
2		Overload, See Pages 26-27	1	31	6-03541	Base, Relay, SHZB-05 IDAC	1
3	10-08008	Label, Control Panel w/Instr.	1	32	6-0504	Block Terminal	1
4		▲ Fuse, Primary, See Pages 26-27	1	33	2-010019	Hanger, Pipe, 1-1/2"	3
5		▲ Fuse, Secondary, See Pages 26-27	1	34	90-1994	Screw, 10/32" x 1-1/4" RH 51	1
6		Transformer, See pages 26-27	1	35	90-017	Nut, 10/32"	1
7	2-0103	Grommet, Rubber, Nozzle	4	36	2-01168	Cap, Rubber, Capacitor	3
8	6-020240	Switch, Rocker, Carling, Green	1	37	N/A	Capacitor, Run	1
9	6-020241	Switch, Rocker, Carling, Red	1	38	N/A	Capacitor, Start	2
10	4-050822	Hour Meter, 115/240VAC, 50/60HZ (886541)	1	39	6-05152	Strain Relief, LQ Tite	1
11	6-021595	Din Rail Track (4-2000A,G; 4-3000A,G;5-3000H) (3-1100D;4-2000B,C,G,H; 4-3000B,C,F,H,N; 5-3000B,C,F,N)	3" 6"	40	6-05153	Strain Relief, LQ Tite (4-3A; 4-3G)	1
12	6-03700	Timer, Multi-Function, 24V, 120/240V	1	41	90-20012	Nut, 5/16" Flange, Whiz Loc	6
13	11-1042	Label, Ground	1	42	90-180101	Screw, 8-32 x 1/2" M TPG PH PNI, Black	23
14	10-08021	Label, Disconnect Pwr Supply	1	43	2-40811	Gasket, Electrical Box, Long	2
15	4-05088	Thermostat, Adjustable, 302°F	1	44	2-4081	Gasket, Electrical Box, Short	2
16	10-02033	Label, Thermostat w/Numbers	1	45	2-01411	Snap Bushing, 3/4"	1
17	6-0128	Conduit, Watertight	22"	46	6-01060	Cord, W/ GFCI Plug, 120V 20A, 36 (3-1100)	1
18	6-051532	Strain Relief, LQ Tite (3-1100)	1		6-01059	Cord, W/ GFCI 240V, 30A, 36 (4-2000A)	1
	6-05170	Strain Relief, 3/4"(4-3A;4-3G; 5-3B)	1		6-010690	Cord, GFCI, 240V 40 AMP (4-2000G, 4-3000A/G)	1
	6-051595	Strain Relief, STRT, LQ Tite (All Models Except 3-1100;4-3A,G; 5-3B)	1		6-0105	Cord, Service, SEO, 12/4 (4-2000B,C,F,N;4-3000C,F,N; 5-3000C,F,N)	36 ft.
19	6-05159	Connector, Straight	1		6-01021	Cord, Service, SO 8/4 (5-3000B,H)	36 ft.
20	95-07101242	Assy, Elect. Box, PHWS, HOT, OHW	1		6-0109	Cord, Service, SEO 10/4 (4-2000B,H, 4-3000B,H)	36 ft.
21	95-07104154	Plate, Stand-Off, E-Bar, PHWS	1	47	4-12804500	Nozzle, SAQCMEG, 0004.5, Red (4-3000)	1
22	95-07121029	Lid, Elect. Box, PHWS, HOT, OHW	1		4-12804515	Nozzle, SAQCMEG, 1504.5, Yellow (4-3000)	1
23	95-07121117	Cover, Elect. Switch, Series II, LQT	1		4-12804525	Nozzle, SAQCMEG, 2504.5, Green (4-3000)	1
24	10-020113	Label, Series II, Control Box	1		4-12804540	Nozzle, SAQCMEG, 4004.5, White (4-3000)	1
25	6-051595	Strain Relief	1		4-12805000	Nipple, SAQCMEG, 0005,Red (3-1100)	1
26	2-408111	Gasket, Strain Relief	2		4-12805015	Nozzle, SAQCMEG, 1505, Yellow (3-1100)	1
27	6-05181B	Locknut, 3/4", 8465	2		4-12805025	Nozzle, SAQCMEG, 2505, Green (3-1100)	1
28	6-05181A	Locknut, 1/2", 8463	3				
29	6-05172	Lock Nut, 3/4" Conduit	1				

**PHWS CONTROL PANEL
ALL MODELS PARTS LIST**

ITEM	PART NO.	DESCRIPTION	QTY
47	4-12805040	Nozzle, SAQCMEG, 4005, White (3-1100)	1
	4-12805500	Nozzle, SAQCMEG, 00055, Red (5-3000)	1
	4-12805515	Nozzle, SAQCMEG, 15055, Yellow (5-3000)	1
	4-12805525	Nozzle, SAQCMEG, 25055, Green (5-3000)	1
	4-12805540	Nozzle, SAQCMEG, 40055, White (5-3000)	1
	4-12806000	Nozzle, SAQCMEG, 0006, Red (4-2000)	1
	4-12806015	Nozzle, SAQCMEG, 1506, Yellow (4-2000)	1
	4-12806025	Nozzle, SAQCMEG, 2506, Green (4-2000)	1
	4-12806040	Nozzle, SAQCMEG, 4006, White (4-2000)	1
48	6-7103002	Wire Assy, 10 Gauge, 8 Wire, 20",	1

▲ Not Shown


**PHWS VALVES
EXPLODED VIEW & PARTS LIST**



ITEM	PART NO.	DESCRIPTION	QTY
1	2-3015	Valve, Flow Control, Chemical	1
2	2-30151	Valve, Flow Control, Steam	1
3	2-1085	Hose Barb, 1/4" Barb x 1/4" Pipe	3
4	2-9040	Clamp, Hose	3
5	2-00601	Elbow, 1/2" JIC x 3/8 Fem, 90°	1
6	4-02021236	Hose, 1/4", 2 Wire, Gauge	36"

ITEM	PART NO.	DESCRIPTION	QTY
7	4-0208000	Tube, 1/4" x 1/2" Clear	8 ft.
8	4-02090000	Hose, 1/4" x 1/2" x 36" Braided Vinyl	3 ft.
9	10-020115	Dual Valve Cover, w/Steam, Lable Series II	1
10	95-07121118	Cover, Dual Valves, Series II Control Box	1
11	90-180101	Screw, 8-32 x 1/2" MT TPG PH	4
12	2-01107	Weather Stripping	


**PHWS COMBUSTION ASSEMBLY
ALL MODELS**



**PHWS COMBUSTION ASSEMBLY
ALL MODELS PARTS LIST**

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	10-02025A	Label, Hot/Caliente	1	24	6-05159	Connector, Straight	1
2		Burner Assy, See Pages 26-27	1	25	90-20040	Nut, 3/8" Flange, Whiz Loc	5
3	2-0039	Cross, 1/2" Female, Steel	1	26	90-4002	Washer, Flat, SAE, 3/8"	2
4	2-00602	Elbow, 1/2" JIC x 1/2" Fem.	1	27	90-1019	Bolt, 3/8" x 1-3/4"	2
5	2-00091	Nipple, Galv., 1/2" x 3", Sch. 80	1	28	2-1022	Elbow, Street, 1/4"	1
6	95-07121113	Insulation Retainer	2	29	2-1002	Nipple, Close, 1/4"	1
7	7-0144	Gasket, Burner Plate	2	30	2-9905	Filter, Fuel Oil/H ₂ O Separator	1
8	4-02047725	Hose, Pres. Loop, 100R2, 25"x3/8"	1		2-99051	Element, Fuel/H ₂ O Separator	1
9	2-00101	Nipple, Galv., 1/2" x 4", Sch. 80	1	31	2-1089	Hose Barb, 90°, 1/4" Barb x 1/4" Pipe	1
10	2-00120	Nipple, Galv., 1/2" x 5", Sch. 80	1	32	2-9040	Clamp, Hose, UNI .46 - .54	2
11	2-00241	Coupling, 1/2" x 3/8"	1	33	4-02100000	Hose 1/4", Fuel Line (12")	2
12	2-2007	Nipple, 3/8" x 3/8" NPT ST Male	1	34	2-1085	Hose Barb 1/4" Barb x 1/4" ML Pipe	1
13	7-0140	Insulation, Front Head, No Hole	1	35	2-1108	Hose Barb, 1/2" Barb x 3/8" MPT, Push-On	1
14	4-05088	Thermostat, General, 302°	1	36	4-02110000	Hose, 1/2" Push On	1.2 ft.
15	2-3409	Rupture Disk Assy, 7000 PSI	1	37	2-1019	Elbow, 3/8" Female	1
16	95-07121015	Bottom Wrap, Stainless Steel	1				
17	95-07121212	Coil Replacement, Schedule 80 W/ Steel Wrap	1				
18	7-01430	Insulation, Blanket w/ No Foil 24" x 57"	1				
19	7-0141	Insulation, Burner Head, W/ Hole	1				
20	7-31332	Gasket Standard - Large	2				
21	95-07121014S	Top Wrap, Stainless Steel	1				
22	2-01104	Trim, 1/16" Black, 750B-2	3.25 ft.				
23	7-01484	Insulation, Blanket - Die Cut, 28"1					

PHWS CHASSIS
ALL MODELS




**PHWS CHASSIS
ALL MODELS PARTS LIST**

ITEM	PART NO.	DESCRIPTION	QTY
1	95-07121017	Panel, Rear Access	1
2	90-50031	Knob, Black 3 Pt, 5/16"-18 x 1"	2
	90-2023	▲ Nut, Cage, 5/16"-18, Black	2
3	90-4001	Washer, 5/16", Flat SAE	2
4	90-1995	Screw, 1/4" x 1/2", BH SOC CS	4
5	90-2000	Nut, 1/4", ESNA, NC	2
6	95-07121010S	Chassis, All	1
7	2-01101	Grip, Handle (Waffle), 1"	2
8	95-07121110	Handle, "J", PHW, PHWS	2
9	2-01157	Cap, PHW W/ Fuel Gauge, 14"	1
10	2-010063	Dip Tube, Plastic	12"
11	2-01164	Tank, Float, Universal Plastic	1
12	95-07121207	Lid & Hinges, Plastic Float Tank	1
13	10-99079	Label, Landa Stripe	1
14	95-07101012A	Axle, 28.5", PHWS	2
15	4-02100013	Inlet Hose, Supply Water, (4-2000, 4-3000, 5-3000)	13"
16	4-02100009	Inlet Hose, Supply Water	11"
17	4-0304	Wheel & Tire Complete, 4" Mag	4
18	90-20041	Collar, 5/8" Bore Shaft 3010	4
19	2-1053	Nipple, 1/2" JIC x 1/2" Pipe	1
20	95-07162007	Hose Connection Bracket, PHWS	1
21	2-10942	Swivel, 1/2" MP x 3/4" GHF	1
22	2-1902	Strainer, Inlet Garden Hose	1


ITEM	PART NO.	DESCRIPTION	QTY
23	90-1999	Screw, 10/32" x 3/4", BH SOC CS	6
24	90-40002	Washer, 1/4", SAE, Black Zinc	4
25	90-2018	Nut, Cage, 10/32" x 16 Ga.	6
26	90-20231	Nut, Cage, 1/4" x 12 Ga.	2
27	2-1042	Tee, 1/2" Street (4-2000, 4-3000 5-3000)	1
28	2-1062	Elbow, 1/2" JIC x 1/2", 90° (4-2000, 4-3000, 5-3000)	1
29	10-020110	Label, Use Only Kerosene	1
30	2-010066	Elbow, Fuel, Tank	1
31	90-5016	Nut, 3/8" - 16 NC Kimdorf W/Spring	2
32	90-4002	Washer, 3/8", SAE, Flat	2
33	90-1017	Bolt, 3/8" x 1-1/4", NC HH	2
34	90-1020	Bolt, 3/8" x 2", NC HH	6
35	90-2019	Nut, Cage, 3/8" x 16 GA	2
36	90-2002	Nut, 3/8" ESNA	4
37	95-07290086	Assy, Lever, Brake	1
38	90-1992	Bolt, 3/8" x 3/8" Sckt Shdr	1
39	90-2001	Nut, 5/16" ESNA	1
40	90-4002	Washer, 3/8" Flat	10
41	2-01212	Cap, Vinyl Flat, Yellow	1
42	2-1085	Hosebarb, 1/4" Barb x 1/4" ML Pipe	1
43	2-9040	Clamp, Hose, UNI .46 - .54	4
44	4-02100000	Hose, 1/4", Fuel Line (12")	2
45	2-010061	Bushing, Mount, Rubber	2
46	2-01104	Trim Lok	22"
47	10-02028	Label, Warning - Exposed Pulleys	1
48	90-200012	Nut, 1/4" Whiz Loc	8

▲ Not Shown

PHWS PUMP ASSEMBLIES
PHWS 3-1100



PHWS 4-2000, 4-3000, 5-3000




PHWS PUMP ASSEMBLIES

PARTS LIST

ITEM	PART NO.	DESCRIPTION	QTY
1	95-07121112	Rail, Pump Combo	1
2	1-96710600	Washer (Landa Pumps)	4
3	1-99364400	Screw (Landa Pumps)	4
4		Pump, See Page 28	1
5	4-02110000	Hose, 1/2" Push-On	12"
6	2-1105	Swivel, 1/2" JIC Fem., Push-On (3-1100, 4-2000, 4-3000)	2
	2-11050	Swivel, 3/4" JIC Fem., Push-On (5-3000)	2
7	2-0079	Swivel, 1/2" JIC Fem., 3/8" Male	1
8	2-0053	Elbow, 1/2" JIC x 3/8", 90°	1
9	6-021740	Replacement, Reed, MV 60	1
10	4-0211000	Hose, 1/2" Push-On (All Models Except 5-3000)	1 ft.
	4-02120000	Hose, 3/4" Push-On (5-3000)	1 ft.
11	4-02047725	Hose, 25" x 3/8", 100R2 Pressure Loop	1
12	2-1062	Elbow, 1/2" JIC x 1/2", 90°	1

ITEM	PART NO.	DESCRIPTION	QTY
13	2-10421	Tee, 1/2" W/1/8" Hose, Street	1
14	2-1084	Hose Barb, 1/4" Barb x 1/8" ML Pipe	1
15	2-9040	Clamp, Hose, UNI .46 - .54	1
16	2-00270	Elbow, 3/8" Male	1
17	2-1052	Nipple, 1/2" JIC x 3/8", 90°	1
18	2-10630	Elbow, 3/4" JIC x 1/2" (5-3000)	1
	2-1062	Elbow, 1/2" JIC x 1/2", 90° (4-2000, 4-3000)	
19	2-0051	Nipple, 1/2" JIC, 3/8" Male	1
	2-00510	Nipple, 1/2" x 3/8" FEM (Auto Start/Stop Option)	1
20	5-3208	Unloader, AL607	1
	5-3027	Unloader, VB8 W/Switch (Auto Start/Stop Option)	1
21	6-021730	Switch, Flow MV60 (Yellow)	1
22	2-30082	Protector, Pump, 1/2" PTP	1
23	2-1042	Tee, 1/2" Street (3-1100)	1
24	2-0031	Elbow, 3/8" Steel	1
25	2-00682	Bushing, 3/8" x 1/4" Steel	1
26	2-1089	Hose Barb, 1/4" x 1/8" M Pipe	1
27	2-1105	Swivel, 1/2" JIC Female, Push-On	2

PHWS FLOAT TANK
ALL MODELS




3-1100

4-2000, 4-3000, 5-3000

ITEM	PART NO.	DESCRIPTION	QTY
1	2-3014	Valve, Float, Fluid Master, 400A (3-1100) (4-2000, 4-3000, 5-3000)	1 2
2	2-01164	Tank, Plastic, Universal Float	1
3	95-07121207	Lid & Hinges, Plastic Float	1
4	10-99079	Label, Landa	1
5	2-10065	Modified Close Nipple, 1/2" NPT (3-1100)	1
	2-1053	Nipple, 1/2" JIC x 1/2" Pipe (4-2000, 4-3000, 5-3000)	1
6	2-1906	Strainer, Basket, 1/2"	1
7	90-4017	Washer, 1-3/16" x 2-1/4" STL RBR	1

ITEM	PART NO.	DESCRIPTION	QTY
8	2-11041	Connector, Anchor, 1/2"	1
9	4-02100013	Inlet Hose, Supply Water (4-2000, 4-3000, 5-3000)	13"
10	2-0151	Plug Float Tank Assy. (#10-13)	1
	90-4030	Screw, 5/16"-18 x 1-1/2" SS, Button	1
11	90-4031	Nut, 5/16"-18, Wing, SS	1
12	90-4032	Washer, 5/16", SS	1
13	4-02140000	Tubing, 5/16" x 9/16", Rubber	1
14	4-02100009	Inlet Hose, 11" Supply Water	1


HOSE & SPRAY GUN ASSEMBLY
ALL MODELS



ITEM	PART NO.	DESCRIPTION	QTY
1	2-2001	Coupler, 1/4", Male	1
	2-0119	▲ O-Ring, Sm Coupler, High Heat, 1/4"	1
2	4-011143A	Wand, SS, V.P. Wand, AR (AL 344) W/Coupler	1
	4-0111391	Wand Only, SS.V.P. Wand, AR (AL 344)	1
	83-SSVPKIT	Repair Kit, AR SS Seat (AL 334, 344)	1

ITEM	PART NO.	DESCRIPTION	QTY
3	4-06540	Nozzle Only, 1/8"	1
4	4-01212	Spray Gun, Shut-Off, Series 2000	1
5	4-02043450C	Hose Only, 50' x 3/8", 100R2 W/Coupler	1
6	2-2002	Coupler, 3/8" Female	1
	2-0121	▲ O-Ring, LG, Coupler, High Heat, 3/8"	1
		▲ Not Shown	

**PHWS POWER PLATFORM
ALL MODELS**



**PHWS POWER PLATFORM
ALL MODELS PARTS LIST**

ITEM	PART NO.	DESCRIPTION	QTY
1	90-10220	Bolt, 3/8" x 3-1/2", Tap (3-1100)	2
	90-1025	Bolt, 3/8" x 5-1/2", NC HH Tap (4-2000, 4-3000, 5-3000)	2
2	6-01041	Service Cord 12/3 (3-11D)	4.25 ft.
	6-0108	Service Cord 10/3 (4-2A,G)	4.25 ft.
	6-0102	Service Cord 8/3 (4-3A, G)	4.25 ft.
	6-0105	Service Cord 12/4 (4-2B,C,F,H; 4-3C,F,N;5-3C,F,N)	4.25 ft.
	6-0109	Service Cord 10/4 (4-3B,H)	4.25 ft.
	6-01021	Service Cord 8/4 (5-3B, H)	4.25 ft.
3	90-1016	Bolt, 3/8" x 1", NC HH (3-1100)	6
		(4-2000, 4-3000, 5-3000)	4
4	90-1007	Bolt, 5/16" x 1", NC HH (3-1100)	4
	90-1016	Bolt, 3/8" (4-2000, 4-3000, 5-3000)	4
5	90-4002	Washer, 3/8" SAE, Flat(3-1100)	16
		(4-2000, 4-3000, 5-3000)	12
6	90-4001	Washer, 5/16", SAE, Flat (3-1100)	8
	90-4002	Washer, 3/8" (4-2000, 4-3000, 5-3000)	8
7	90-2007	Nut, 3/8", Hex, NC	2
8	90-2002	Nut, 3/8", ESNA, NC (3-1100)	6
		(4-2000, 4-3000, 5-3000)	4
9	90-2001	Nut, 5/16", ESNA, NC (3-1100)	4
	90-2002	Nut, 3/8", ESNA (4-2000, 4-3000, 5-3000)	4

ITEM	PART NO.	DESCRIPTION	QTY
10	95-07141110	Retainer, Pump Take Up (3-1100)	1
11	95-07121010S	Chassis, All	1
12	95-07121013	Platform, Motor (3-1100)	1
	95-071210136	Platform, Motor, 3/16" (4-2000, 4-3000, 5-3000)	1
13		Belt, See Page 29	1
14		Pulley, Motor, See Page 28	1
15		Bushing, Pump, See Page 28	1
16		Bushing, Motor, See Page 29	1
17		Motor, See Page 28-29	1
18		Pulley, Pump, See Page 28	1
19	6-051595	Strain Relief (4-3000A)	1
20	6-051532	Strain Relief (4-3000A)	1
21	6-041042	Box, Junction, 4" x 4", 5 Hole (4-3000A)	1
22	6-041043	Cover, Junction Box (4-3000A)	1
23	90-19711	▲ Screw, 1/4" x 1/2" Whiz (4-3000A)	4
24	6-0125	Conduit, Flexo	5 ft.
	6-01132	▲ Wire, MTW, 12 AWG, White (4-3000A)	15 ft.
25	6-0102	Cord Service, 50 8/3 (4-3000A)	4.25 ft.
26	6-051532	Strain Relief, 1/2" LQ Tite, Motor (3-1100)	1
	6-051595	Strain Relief, 3/4" LQ Tite, Motor (All Models Except 3-1100, 4-3A, 4-3G, 5-3B)	1
	6-05170	Strain Relief, 3/4" Galvanized, Watertight, Motor (4-3A, 4-3G, 5-3B)	1

▲ Not Shown

BECKETT BURNER SPECIFICATIONS

Model No.	Burner Assy No.	Fuel Nozzle	Transformer	Burner Motor	Fuel Pump/ Solenoid/Cord	Fuel Solenoid Coil	Electrode
PHWS3-11021D	7-00013	7-01245	7-23581	7-21805U	7-21844U	7-21755U	7-578703
PHWS3-11024D	7-00013	7-01245	7-23581	7-21805U	7-21844U	7-21755U	7-578703
PHWS4-20021A	7-00010	7-0103	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-20024A	7-00010	7-0103	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-20021B	7-00010	7-0103	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-20024B	7-00010	7-0103	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-20021C	7-00011	7-0103	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS4-20024C	7-00011	7-0103	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS4-20024F	7-00011	7-0103	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS4-20021G	7-00010	7-0103	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-20024G	7-00010	7-0103	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-20021H	7-00010	7-0103	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-20024H	7-00010	7-0103	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-30021A	7-00010	7-0101	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-30024A	7-00010	7-0101	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-30021B	7-00010	7-0101	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-30024B	7-00010	7-0101	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-30021C	7-00011	7-0101	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS4-30024C	7-00011	7-0101	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS4-30021F	7-00011	7-0101	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS4-30024F	7-00011	7-0101	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS4-30021G	7-00010	7-0101	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-30024G	7-00010	7-0101	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-30021H	7-00010	7-0101	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS4-30024H	7-00010	7-0101	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS5-30021B	7-00010	7-01284	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS5-30024B	7-00010	7-01284	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS5-30021C	7-00011	7-01284	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS5-30024C	7-00011	7-01284	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS5-30021F	7-00011	7-01284	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS5-30024F	7-00011	7-01284	7-51824	7-21344U	7-21844U	7-21755U	7-578703
PHWS5-30021H	7-00010	7-01284	7-21176U	7-2899U	7-21844U	7-21755U	7-578703
PHWS5-30024H	7-00010	7-01284	7-21176U	7-2899U	7-21844U	7-21755U	7-578703

WAYNE BURNER SPECIFICATIONS

Model No.	Burner Assy No.	Fuel Nozzle	Transformer	Burner Motor	Fuel Pump	Fuel Solenoid Coil	Electrode
PHWS3-11021D	7-00034	7-0123	7-20358	7-0005	7-0009	7-0009611	7-13286
PHWS4-20021A	7-00033	7-0126	7-21153	7-0005	7-0009	7-0009611	7-13286
PHWS4-20021B	7-00033	7-0126	7-21153	7-0005	7-0009	7-0009611	7-13286
PHWS4-20021C	7-00034	7-0126	7-20358	7-0005	7-0009	7-0009611	7-13286
PHWS4-20021G	7-00033	7-0126	7-21153	7-0005	7-0009	7-0009611	7-13286
PHWS4-20021H	7-00033	7-0126	7-21153	7-0005	7-0009	7-0009611	7-13286
PHWS4-30021A	7-00033	7-0124	7-21153	7-0005	7-0009	7-0009611	7-13286
PHWS4-30021B	7-00033	7-0124	7-21153	7-0005	7-0009	7-0009611	7-13286
PHWS4-30021C	7-00034	7-0124	7-20358	7-0005	7-0009	7-0009611	7-13286
PHWS4-30021F	7-00034	7-0124	7-20358	7-0005	7-0009	7-0009611	7-13286
PHWS4-30021G	7-00033	7-0124	7-21153	7-0005	7-0009	7-0009611	7-13286
PHWS4-30021H	7-00033	7-0124	7-21153	7-0005	7-0009	7-0009611	7-13286
PHWS4-30024N	7-00042	7-0124	7-20393	7-20383	7-13645	7-0009611	7-13286
PHWS5-30021B	7-00033	7-0127	7-21153	7-0005	7-0009	7-0009611	7-13286
PHWS5-30021C	7-00034	7-0127	7-20358	7-0005	7-0009	7-0009611	7-13286
PHWS5-30021F	7-00034	7-0127	7-20358	7-0005	7-0009	7-0009611	7-13286
PHWS5-30021H	7-00033	7-0127	7-21153	7-0005	7-0009	7-0009611	7-13286
PHWS5-30024N	7-00042	7-0127	7-20393	7-20387	7-13645	7-0009611	7-13286

PARTS SPECIFICATIONS: LANDA PUMP

Machine Model	PUMP						MOTOR						
	Pump Model	Part #	Pulley Part #	Bushing Part #	Size	Voltage/PH	Hertz	Part #	Pulley Part #	Bushing			
3-11024D	LM4035	5-1720	AK84H 5-40108401	24mm	5-512024	2-HP	120V/1PH	60	5-1047	AK20 x5/85-40102058	N/A		
4-20024A	LT5030	5-1728	2AK84H 5-40208401	25mm	5-512025	6-HP	230V/1PH	60	5-10401	2AK46H 5-40204601	1-1/8"		
4-20024B	LT5030	5-1728	2AK84H 5-40208401	25mm	5-512025	6HP	230V/3PH	60	5-1011	2AK46H 5-40204601	1-1/8"		
4-20024C	LT5030	5-1728	2AK84H 5-40208401	25mm	5-512025	6-HP	460V/3PH	60	5-1011	2AK46H 5-40204601	1-1/8"		
4-20024F	LT5030	5-1728	2AK84H 5-40208401	25mm	5-512025	5HP	575V/3PH	60	5-1027	2AK34H 5-40203401	1-1/8"		
4-20024G	LT5030	5-1728	2AK84H 5-40208401	25mm	5-512025	6HP	208V/1PH	60	5-10402	2AK44H 5-40204401	1-1/8"		
4-20024H	LT5030	5-1728	2AK84H 5-40208401	25mm	5-512025	6HP	208V/3PH	60	5-10111	2AK44H 5-40204401	1-1/8"		
4-30024A	LT5030	5-1728	2BK80H 5-40508001	25mm	5-512025	8.2HP	230V/1PH	60	5-1082	2BK34H 5-40503401	1-3/8"		
4-30024B	LT5030	5-1728	2BK80H 5-40508001	25mm	5-512025	8.2HP	230V/3PH	60	5-1083	2BK34H 5-40503401	1-3/8"		
4-30024C	LT5030	5-1728	2BK80H 5-40508001	25mm	5-512025	8.2HP	460V/3PH	60	5-1083	2BK34H 5-40503401	1-3/8"		
4-30024F	LT5030	5-1728	2BK90H 5-40509001	25mm	5-512025	71/2HP	575V/3PH	60	5-10146	2BK36H 5-40503601	1-3/8"		
4-30024G	LT5030	5-1728	2BK80H 5-40508001	25mm	5-512025	8.2HP	208V/1PH	60	5-1080	2BK34H 5-40503401	1-3/8"		
4-30024H	LT5030	5-1728	2BK80H 5-40508001	25mm	5-512025	8.2HP	208V/3PH	60	5-1081	2BK34H 5-40503401	1-3/8"		
4-30024N	LT5030	5-1728	2BK70H 5-40507001	25mm	5-512025	71/2HP	380V/3PH	50	5-1063	2BK34H 5-40503401	1-3/8"		
5-30024B	LT5030	5-1728	2BK65H 5-40506501	25mm	5-512025	10HP	230V/3PH	60	5-1018	2BK36H 5-40503601	1-3/8"		
5-30024C	LT5030	5-1728	2BK65H 5-40506501	25mm	5-512025	10HP	460V/3PH	60	5-1018	2BK36H 5-40503601	1-3/8"		
5-30024F	LT5030	5-1728	2BK65H 5-40506501	25mm	5-512025	10HP	575V/3PH	60	5-1026	2BK36H 5-40503601	1-3/8"		
5-30024H	LT5030	5-1728	2BK65H 5-40506501	25mm	5-512025	10HP	208V/3PH	60	5-10151	2BK36H 5-40503601	1-3/8"		
5-30024N	LT5030	5-1728	2BK70H 5-40507001	25mm	5-512025	10HP	380V/3PH	50	5-1089	2BK47H 5-40504701	1-3/8"		

PARTS SPECIFICATIONS: GENERAL PUMP

Machine Model	PUMP						MOTOR						
	Pump Model	Part #	Pulley Part #	Bushing Part #	Size	Voltage/PH	Hertz	Part #	Pulley Part #	Bushing			
3-11021D	T991	5-2302	AK84H 5-40208401	24mm	5-512024	2HP	120V/1PH	60	5-1047	AK26x5/8"5-40102658	N/A		
4-20021A	T1011	5-2304	2AK84H 5-40208401	24mm	5-512024	6HP	230V/1PH	60	5-10401	2AK54H 5-40205401	1-1/8"		
4-20021B	T1011	5-2304	2AK84H 5-40208401	24mm	5-512024	6HP	230V/3PH	60	5-1011	2AK54H 5-40205401	1-1/8"		
4-20021C	T1011	5-2304	2AK84H 5-40208401	24mm	5-512024	6HP	460V/3PH	60	5-1011	2AK54H 5-40205401	1-1/8"		
4-20021G	T1011	5-2304	2AK84H 5-40208401	24mm	5-512024	6HP	208V/1PH	60	5-10402	2AK54H 5-40205401	1-1/8"		
4-20021H	T1011	5-2304	2AK84H 5-40208401	24mm	5-512024	6HP	208V/3PH	60	5-10111	2AK54H 5-40205401	1-1/8"		
4-30021A	TS2021	5-2307	2BK80H 5-40508001	24mm	5-512024	8.2HP	230V/1PH	60	5-1082	2BK50H 5-40505001	1-3/8"		
4-30021B	TS2021	5-2307	2BK80H 5-40508001	24mm	5-512024	8.2HP	230V/3PH	60	5-1083	2BK50H 5-40505001	1-3/8"		
4-30021C	TS2021	5-2307	2BK80H 5-40508001	24mm	5-512024	8.2HP	460V/3PH	60	5-1083	2BK50H 5-40505001	1-3/8"		
4-30021F	TS2021	5-2307	2BK80H 5-40508001	24mm	5-512024	71/2HP	575V/3PH	60	5-10146	2BK45H 5-40504501	1-3/8"		
4-30021G	TS2021	5-2307	2BK80H 5-40508001	24mm	5-512024	8.2HP	208V/1PH	60	5-1080	2BK50H 5-40505001	1-3/8"		
4-30021H	TS2021	5-2307	2BK80H 5-40508001	24mm	5-512024	8.2HP	208V/3PH	60	5-1081	2BK50H 5-40505001	1-3/8"		
5-30021B	TS2021	5-2307	2BK70H 5-40507001	24mm	5-512024	10HP	230V/3PH	60	5-1018	2BK57H 5-40505701	1-3/8"		
5-30021C	TS2021	5-2307	2BK70H 5-40507001	24mm	5-512024	10HP	460V/3PH	60	5-1018	2BK57H 5-40505701	1-3/8"		
5-30021F	TS2021	5-2307	2BK70H 5-40507001	24mm	5-512024	10HP	575V/3PH	60	5-1026	2BK57H 5-40505701	1-3/8"		
5-30021H	TS2021	5-2307	2BK70H 5-40507001	24mm	5-512024	10HP	208V/3PH	60	5-10151	2BK57H 5-40505701	1-3/8"		

PARTS SPECIFICATIONS: LANDA PUMP (CON'T)

MOTOR (CON'T)						CONTROLS				
Model (Con't)	Bushing Part #	Belt Size/Qty	Belt Part #	Motor Contactor	Motor Overload	Stepdwn Transformer	Primary Fuse	Primary Fuse Part #	Secondary Fuse	Secondary Fuse Part #
3-11D	N/A	AX34 (1)	5-602034	6-4010	N/A	N/A	N/A	N/A	N/A	N/A
4-2A	5-511113	AX36 (2)	5-602036	6-4018	N/A	6-60101	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-2B	5-511113	AX36 (2)	5-602036	6-4010	6-5011	6-60101	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-2C	5-511113	AX36 (2)	5-602036	6-4004	6-5009	6-60021	3 Amp	6-02306 (2)	8 Amp	6-022910
4-2F	5-511113	AX34 (2)	5-602034	6-4000	6-5007	6-60011	3 Amp	6-02306 (2)	8 Amp	6-022910
4-2G	5-511113	AX35 (2)	5-602035	6-4018	N/A	6-60141	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-2H	5-511113	AX35 (2)	5-602035	6-4013	6-5012	6-60141	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-3A	5-511138	BX34 (2)	5-604034	6-4021	6-5015	6-60101	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-3B	5-511138	BX34 (2)	5-604034	6-4010	6-5012	6-60101	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-3C	5-511138	BX34 (2)	5-604034	6-4007	6-5009	6-60021	3 Amp	6-02306 (2)	8 Amp	6-022910
4-3F	5-511138	BX36 (2)	5-604036	6-4000	6-5009	6-60011	3 Amp	6-02306 (2)	8 Amp	6-022910
4-3G	5-511138	BX34 (2)	5-604034	6-4021	6-5015	6-60141	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-3H	5-511138	BX34 (2)	5-604034	6-4018	6-5014	6-60141	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-3N	5-511138	BX32 (2)	5-604032	6-4010	6-5010	6-60011	3 Amp	6-02306 (2)	8 Amp	6-022910
5-3B	5-511138	BX32 (2)	5-604032	6-4018	6-5012	6-60101	1 Amp	6-02294 (2)	1/2 Amp	6-022970
5-3C	5-511138	BX32 (2)	5-604032	6-4007	6-5011	6-60021	3 Amp	6-02306 (2)	8 Amp	6-022910
5-3F	5-511138	BX32 (2)	5-604032	6-4004	6-5010	6-60011	3 Amp	6-02306 (2)	8 Amp	6-022910
5-3H	5-511138	BX32 (2)	5-604032	6-4018	6-5014	6-60141	1 Amp	6-02294 (2)	1/2 Amp	6-022970
5-3N	5-511138	BX34 (2)	5-604034	6-4010	6-5011	6-60011	3 Amp	6-02306 (2)	8 Amp	6-022910

PARTS SPECIFICATIONS: GENERAL PUMP (CON'T)

MOTOR (CON'T)						CONTROLS				
Model (Con't)	Bushing Part #	Belt Size/Qty	Belt Part #	Motor Contactor	Motor Overload	Stepdown Transformer	Primary Fuse	Primary Fuse Part #	Secondary Fuse	Secondary Fuse Part #
3-11D	N/A	AX33 (1)	5-602033	6-4010	N/A	N/A	N/A	N/A	N/A	N/A
4-2A	5-511113	AX37 (2)	5-602037	6-4018	N/A	6-60101	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-2B	5-511113	AX37 (2)	5-602037	6-4010	6-5011	6-60101	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-2C	5-511113	AX37 (2)	5-602037	6-4004	6-5009	6-60021	3 Amp	6-02306 (2)	8 Amp	6-022910
4-2G	5-511113	AX37 (2)	5-602037	6-4018	N/A	6-60141	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-2H	5-511113	AX37 (2)	5-602037	6-4013	6-5012	6-60141	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-3A	5-511138	BX36 (2)	5-604036	6-4021	6-5015	6-60101	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-3B	5-511138	BX36 (2)	5-604036	6-4010	6-5012	6-60101	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-3C	5-511138	BX36 (2)	5-604036	6-4007	6-5009	6-60021	3 Amp	6-02306 (2)	8 Amp	6-022910
4-3F	5-511138	BX36 (2)	5-604036	6-4000	6-5009	6-60011	3 Amp	6-02306 (2)	8 Amp	6-022910
4-3G	5-511138	BX36 (2)	5-604036	6-4021	6-5015	6-60141	1 Amp	6-02294 (2)	1/2 Amp	6-022970
4-3H	5-511138	BX36 (2)	5-604036	6-4018	6-5014	6-60141	1 Amp	6-02294 (2)	1/2 Amp	6-022970
5-3B	5-511138	BX36 (2)	5-604036	6-4013	6-5012	6-60101	1 Amp	6-02294 (2)	1/2 Amp	6-022970
5-3C	5-511138	BX36 (2)	5-604036	6-4007	6-5011	6-60021	3 Amp	6-02306 (2)	8 Amp	6-022910
5-3F	5-511138	BX36 (2)	5-604036	6-4004	6-5010	6-60011	3 Amp	6-02306 (2)	8 Amp	6-022910
5-3H	5-511138	BX36 (2)	5-604036	6-4018	6-5014	6-60141	1 Amp	6-02294 (2)	1/2 Amp	6-022970

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
LOW OPERATING PRESSURE	Faulty pressure gauge	Test with 2nd gauge. If bad, install new gauge.
	Insufficient water supply	Use larger garden hose; clean water filter at inlet. Clean screen inside float tank.
	Old, worn or incorrect nozzle	Match nozzle number to machine and/or replace with new nozzle.
	Belt slippage	Tighten or replace; use correct belt.
	Plumbing or hose leak	Check plumbing system for leaks. Retape leaks with teflon tape.
	Faulty or misadjusted unloader valve	Adjust unloader for proper pressure. Install repair kit when needed. Test PSI with unloader removed, taking pressure directly off the pump.
	Worn packing in pump	Install new packing kit.
	Fouled or dirty inlet or discharge valves in pump	Clean inlet and discharge valves.
	Worn inlet or discharge valves	Replace with valve kit.
	Obstruction in spray nozzle	Remove obstruction.
	Low power supply	Check voltage of building and compare with requirements. Obtain a different power source.
	Detergent metering valve left open sucking air, or faulty metering valve	Close and/or replace metering valve.
BURNER WILL NOT LIGHT	Little or no fuel	Fill tank with fuel.
	Improper fuel or water in fuel	Drain fuel tank and fill with proper fuel.
	Plugged fuel filter	Replace as needed.
	Misadjusted burner air bands	Readjust air bands for clean burn.
	Little or no fuel pressure from fuel pump	Increase fuel pressure to specifications and/or replace fuel pump.
	Faulty burner transformer	Test transformer for proper arc between contacts. Replace as needed.
	Disconnected or short in electrical wiring	All wire contacts should be clean and tight. No breaks in wire.
	Burner motor thermal protector tripped	If tripped, check voltage, connections and extensions for cause. Check fuel pump shaft rotation for binding causing motor to overheat.
	Flex-Coupling slipping on fuel pump shaft or burner motor shaft	Replace if needed.
	ON-OFF switch defective	Check burner switch for continuity.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
BURNER WILL NOT LIGHT (continued)	Heavy sooting on coil and burner can cause interruption of air flow and shorting of electrodes.	Clean as required.
	Improper electrode setting	Clean and set according to diagram in Operator's Manual.
	Fuel not reaching combustion chamber	Check fuel pump for proper flow. Check solenoid flow switch on machines with spray gun control for proper on-off fuel flow control.
	Clogged burner nozzle	Replace.
	Water not flowing through flow switch	Open spray gun to allow water to flow.
	Flow switch malfunction	Remove reed and test for continuity. Replace if needed.
	Fuel solenoid malfunction	Replace if needed.
UNIT SMOKES	Improper fuel or water in fuel	Drain tank and replace contaminated fuel.
	Improper air adjustment	Readjust air bands on burner assembly.
	Low fuel pressure	Call technical support.
	Air leaks in fuel lines	Check fuel lines for leaks or air bubbles. Tighten or replace as needed.
	Plugged or dirty burner nozzle	Replace.
	Faulty burner nozzle spray pattern	Replace nozzle.
	Heavy accumulation of soot on coils and burner assembly	Remove coils and burner assembly. Clean thoroughly.
	Misaligned electrode	Call technical support.
	Obstruction in smoke stack	Check for insulation blockage or other foreign objects.
LOW WATER TEMPERATURE	Improper fuel or water in fuel	Drain fuel tank and replace with proper fuel.
	Low fuel pressure	Increase fuel pressure.
	Weak fuel pump	Check fuel pump pressure. Replace pump if needed.
	Fuel filter partially clogged	Replace if needed.
	Soot build-up on coils	Clean coils with soot remover.
	Lime build-up in coils	Clean inside of coils with coil clean.
	Improper burner nozzle	See tank assembly parts list for correct nozzle.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
WATER TEMPERATURE TOO HOT	Incoming water to machine warm or hot	Lower incoming water temperature.
	Fuel pump pressure too high	Call technical support.
	Fuel pump defective	Replace fuel pump.
	Detergent line sucking air	Tighten all clamps. Check detergent line for holes.
	Defective high limit switch	Replace.
	Incorrect fuel nozzle size	See exploded view parts list for proper size.
	Insufficient water supplied	Check GPM to machine.
	Restricted water flow	Check nozzle for obstruction and proper size.
PUMP MOTOR STOPS AFTER A FEW MINUTES OF OPERATION OR STARTS SLOW	Insufficient voltage	Use heavier drop cord and check voltage at receptacle. Check name plate for amperage draw.
	Plugged nozzle	Remove and clean nozzle. Turn on water pump and flush lines, replace nozzle.
	Wrong spray nozzle	See serial plate for minimum nozzle size.
	Automatic overload switch tripped	Allow motor to cool - switch will automatically reset.
	Motor wet	Allow to dry.
	Short in electrical wiring	Wire contacts should be clean and tight. No breaks in wires.
	Coil liming up causing excessive pressure	See section on Preventative Maintenance.
	Water pump low or out of oil causing the pump to bind up	Fill to correct level.
RELIEF VALVE LEAKS OR SPRAYS OUT WATER	Spray nozzle plugged	Remove nozzle and clean out obstruction.
	Misadjusted or defective relief valve	Adjust or replace as needed.
	Scale or dirt plugging inside of coils	See "Preventative Maintenance Cleaning of Coils."
DETERGENT NOT DRAWING	Air leak	Tighten all clamps. Check detergent lines for holes.
	Detergent metering valve packing not tight or packing worn	Tighten nut. Replace valve or packing.
	Filter screen on detergent suction hose plugged	Clean or replace.
	Dried up detergent plugging metering valve or injector	Clean and flush.
	Restrictor in float tank missing	Install restrictor.
	High viscosity of detergent	Dilute detergent to specifications. Read detergent label.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
MACHINE WILL NOT DRAW UP DETERGENT	Clamps holding detergent lines are loose	Tighten clamps.
	Hole in detergent line(s)	Repair hole.
	Strainer basket plugged	Remove and clean.
BURNER MOTOR WILL NOT RUN	Overload protector tripped	Push reset button.
	Fuel pump seized	Replace fuel pump.
	Burner fan loose or misaligned	Position correctly and tighten set screw.
	Defective control switch	Replace switch.
	Loose wire	Check and replace or tighten wiring.
	Defective burner motor	Replace motor.
EXCESSIVE VIBRATION IN DELIVERY LINE	Irregular functioning of check valves, metering valves	Check and replace if necessary.
TEMPERATURE RELIEF VALVE LEAKS WATER (pump protector)	Spray gun in OFF position with machine operating for an extended period of time	Open spray gun to cool circulating water.
	Relief valve defective	Replace valve.
	Particle next to poppet	Remove internal parts and clean.
BURNER STAYS ON WHEN SPRAY GUN IS IN OFF POSITION	Fuel pump pressure too high	Call technical support.
	Pressure switch defective	Check for proper operation, replace if necessary.
	Fuel solenoid defective	Replace fuel solenoid.
PUMP RUNNING NORMALLY BUT PRESSURE LOW	Pump sucking air	Check water supply and possibility of air seepage.
	Valves sticking	Check and clean or replace if necessary.
	Unloader valve seat faulty	Check and replace if necessary.
	Nozzle incorrectly sized	See serial plate for minimum nozzle size.
	Worn piston packing	Check and replace if necessary.
PUMP NOISY	Air in suction line	Check water supply and connections on suction line.
	Broken or weak inlet or discharge valve springs	Check and replace if necessary.
	Excessive temperature of liquid	Reduce to below 60° C (140° F).
	Foreign matter in valves	Check and clean if necessary.
	Worn bearings	Check and replace if necessary.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
PRESENCE OF WATER IN OIL	Oil seal worn	Check and replace if necessary.
	High humidity in air	Check and change oil twice as often.
	Piston packing worn	Check and replace if necessary.
WATER DRIPPING FROM UNDER PUMP	Piston packing worn	Check and replace if necessary.
	O.R. plunger retainer worn	Check and replace if necessary.
	Cracked ceramics	Check and replace if necessary.
OIL DRIPPING	Oil seal worn	Check and replace if necessary.
	Cracked manifold	Check and replace if necessary.
WON'T START	Faulty timer	By-pass timer by joining wires 15 & 16 on timer together. If it starts, replace timer.
WON'T TIMEOUT	Faulty reed switch	Check for continuity. Replace if necessary.
	Faulty relay or base	Check relay cube or relay base for proper continuity. Replace if necessary.

**TROUBLESHOOTING
UNLOADER**

PROBLEM	POSSIBLE CAUSE	SOLUTION
SYSTEM WILL NOT COME UP TO FULL DESIGNATED PRESSURE	Spray nozzle worn or nozzle orifice is too large in relation to pump flow rate	See serial plate for correct nozzle size.
	Adjusted improperly	Readjust unloader with pressure gauge.
	Bypass valve (within unloader) is obstructed or leaking	Remove and clean bypass cartridge or replace.
	Flow rate of pump inadequate	Assure designated flow rate of pump is adequate in relation to spray nozzle size.
PRESSURE SPIKES IN DISCHARGE LINE DURING BYPASS MODE	Pressure adjustment too tight	Call technical support.
	Restricted bypass line	Bypass line should be 1/2" inside diameter (I.D.), 12" long and of low pressure flexible hose.
	Flow rate higher than 8 gpm	Unloader flow rate is 7.8 gpm maximum.
UNLOADER CYCLES WHILE IN BYPASS MODE	External leak on unloader or in downstream fittings	Inspect all high pressure lines (including spray gun and hose) for any signs of leakage and repair as necessary.
	Discharge valve (within the unloader) damaged, obstructed or worn	Inspect and replace as necessary.
	Weep gun is being used	The unloader is not designed for use with a weep gun.

PREVENTATIVE MAINTENANCE

This pressure washer was produced with the best available materials and quality craftsmanship. However, you as the owner have certain responsibilities for the correct care of the equipment. Attention to regular preventative maintenance procedures will assist in preserving the performance of your equipment. Contact your Landa, Inc. dealer for maintenance. Regular preventative maintenance will add many hours to the life of your pressure washer. Perform maintenance more often under severe conditions.

MAINTENANCE SCHEDULE		
Replace Fuel Lines		Annually
Pump Oil	Inspect	Daily inspect the oil level
	Change	After first 50 hours, then every 500 hours or annually
Clean Burner Filter		Monthly (More often if fuel quality is poor)
Remove Burner Soot		Annually
Burner Adjustment/Cleaning		Annually
Descale Coil		Annually - (more often if required)
Replace High Pressure Nozzle		Every 6 months
Replace Quick Connects		Annually
Clean Water Screen/Filter		Weekly
Clean Float/Supply Tank		Every 6 months
Replace HP Hose		Annually if there is any sign of wear
Grease Motor		Every 10,000 hours
Replace Burner Nozzle		Annually

OIL CHANGE RECORD

Date Oil Changed Month/Day/Year	Estimated Operating Hours Since Last Oil Change



LANDA LIMITED NEW PRODUCT WARRANTY PRESSURE WASHERS

WHAT THIS WARRANTY COVERS

All LANDA pressure washers are warranted by LANDA, INC. to the original purchaser to be free from defects in materials and workmanship under normal use, for the periods specified below. This Limited Warranty is subject to the exclusions shown below, is calculated from the date of the original purchase, and applies to the original components only. Any parts replaced under this warranty will assume the remainder of the part's warranty period.

FIVE YEAR PARTS AND ONE YEAR LABOR WARRANTY:

Components manufactured by LANDA, such as frames, handles, top and bottom wraps, float tanks, fuel tanks, belt guards, and heating coils. Internal components on the oil-end of all branded pumps have a 5 year warranty.

ONE YEAR MINIMUM ON PARTS AND ONE YEAR LABOR WARRANTY:

All other components, excluding normal wear items as described below, will be warranted for one year on parts and labor. Parts and labor warranty on these parts will be for one year regardless of the duration of the original component manufacturer's part warranty.

WARRANTY PROVIDED BY OTHER MANUFACTURERS:

Motors, generators, and engines, which are warranted by their respective manufacturers, are serviced through these manufacturers' local authorized service centers. LANDA cannot provide warranty on these items.

WHAT THIS WARRANTY DOES NOT COVER

This warranty does not cover the following items:

1. Normal wear items, such as nozzles, guns, discharge hoses, wands, quick couplers, seals, filters, gaskets, O-rings, packings, pistons, pump valve assemblies, strainers, belts, brushes, rupture disks, fuses, pump protectors.
2. Damage or malfunctions resulting from accidents, abuse, modifications, alterations, incorrect installation, improper servicing, failure to follow manufacturer's maintenance instructions, or use of the equipment beyond its stated usage specifications as contained in the operator's manual.
3. Damage due to freezing, chemical deterioration, scale build up, rust, corrosion, or thermal expansion.
4. Damage to components from fluctuations in electrical or water supply.
5. Normal maintenance service, including adjustments, fuel system cleaning, and clearing of obstructions.
6. Transportation to service center, field labor charges, or freight damage.

WHAT YOU MUST DO TO OBTAIN WARRANTY SERVICE

While not required for warranty service, we request that you register your LANDA pressure washer by returning the completed registration card. In order to obtain warranty service on items warranted by LANDA, you must return the product to your Authorized LANDA Dealer, freight prepaid, with proof of purchase, within the applicable warranty period. If the product is permanently installed, you must notify your Authorized LANDA Dealer of the defect. Your Authorized LANDA Dealer will file a claim with Landa, who must subsequently verify the defect. In most cases, the part must be returned to LANDA freight prepaid with the claim. For warranty service on components warranted by other manufacturer's, your Authorized LANDA Dealer can help you obtain warranty service through these manufacturers' local authorized service centers.

LIMITATION OF LIABILITY

LANDA'S liability for special, incidental, or consequential damages is expressly disclaimed. In no event shall LANDA'S liability exceed the purchase price of the product in question. LANDA makes every effort to ensure that all illustrations and specifications are correct, however, these do not imply a warranty that the product is merchantable or fit for a particular purpose, or that the product will actually conform to the illustrations and specifications. **THE WARRANTY CONTAINED HEREIN IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.** LANDA does not authorize any other party, including authorized LANDA Dealers, to make any representation or promise on behalf of LANDA, or to modify the terms, conditions, or limitations in any way. It is the buyer's responsibility to ensure that the installation and use of LANDA products conforms to local codes. While LANDA attempts to assure that its products meet national codes, it cannot be responsible for how the customer chooses to use or install the product.

LANDA INC.

1-360-833-9100 • 1-800-547-8672 • www.landa.com

INTRODUCCION

Gracias por comprar un Lavadora a Presión Landa.

Estas instrucciones y advertencias corresponden a los modelo PHWS.

Landa, Inc. se reserva el derecho de hacer cualquier cambio en cualquier momento sin contraer ninguna obligación.

Responsabilidades del Dueño/Usuario:

El dueño y/o usuario debe estar al tanto de las instrucciones de operación y de las advertencias del fabricante antes de usar su lavadora a presión Landa. La información de advertencia debe ser enfatizada y comprendida. Si el operador no domina el inglés, el comprador/dueño deberá leer y discutir con éste las instrucciones y las advertencias del fabricante en el idioma natal del operador, asegurándose de que éste entienda su contenido.

El dueño y/o usuario debe estudiar y mantener las instrucciones del fabricante para futuras referencias.

Este manual debe ser considerado una parte permanente de la máquina y deberá entregarse con la máquina en caso de que se venda.

Cuando ordene las partes, por favor especifique el modelo y el número de serie.

INSTRUCCIONES IMPORTANTES DE SEGURIDAD



PRECAUCION: Para reducir el riesgo de accidentes, lea las instrucciones cuidadosamente antes de usar la unidad.

1. Lea todo el manual para operadores cuidadosamente. Al no seguir las instrucciones puede causar el mal

funcionamiento de la unidad y provocar la muerte, o causar serias heridas y/daños en la propiedad.

2. Todas las instalaciones deben cumplir con los códigos locales. Póngase en contacto con un técnico eléctrico, plomero, compañía de servicios públicos o distribuidor de ventas para mayores detalles.



ADVERTENCIA: Riesgo de asfixia. Use este producto solo en áreas bien ventiladas.

3. Evite instalar unidades en áreas pequeñas o cerca de ventiladores de gases de escape. Los gases de escape contienen gas venenoso de

monóxido de carbono; la exposición puede causar pérdida del conocimiento y causar la muerte. Los gases de escape también contienen químicos, en ciertas cantidades, que se sabe, causan cáncer, defectos de nacimiento, o daños al sistema reproductivo.



ADVERTENCIA: Líquidos inflamables pueden crear gases que se encienden causando daños a la propiedad y heridas severas.

4. Aparatos de encendido con petróleo deberán de ser instalados en lugares donde

residuos de combustibles, vapores o gases inflamables no estén normalmente presentes. En modelos de encendido con petróleo utilice únicamente kerosene #1 o diesel. No utilice gasolina, solventes o alcohol. El utilizarlo resultará en fuego y/o explosión.



ADVERTENCIA: Mantenga el chorro de agua, la varilla y la manguera de alta presión lejos del cableado eléctrico ya que puede ocurrir un choque fatal. Lea la etiqueta de advertencia del cable eléctrico.

5. Para proteger al operador de un choque eléctrico, la máquina deberá de estar conectada a tierra. Es la responsabilidad del dueño de conectar esta máquina a un receptáculo a tierra aprobado por UL con el amperage y voltaje indicados. No moje sobre o cerca de los componentes eléctricos; no toque la máquina con las manos mojadas o cuando esté parado sobre agua. Siempre desconecte la máquina cuando le dé servicio de mantenimiento.


ADVERTENCIA: Sostenga la pistola aspersora con ambas manos ya que con la alta presión esta puede tener retroceso.

6. Sujete firmemente con ambas manos la varilla aspersora antes de encender la maquina; de no seguir esta recomendación puede resultar en heridas por golpe de la misma.
7. No coloque la máquina cerca de objetos inflamables si el motor esta caliente.



ADVERTENCIA: Este equipo puede producir un fluido de alta presión a chorro que puede penetrar la piel y sus tejidos, causando graves heridas y posible amputación.

IDENTIFICACION DE COMPONENTES - PHWS



8. Las altas presiones desorrolladas por esta unidad causarán heridas personales o daño al equipo. Use precaución cuando esté operando el equipo. No dirija el chorro de descarga hacia la gente porque de lo contrario puede causarles heridas graves incluyendo la muerte.
9. Nunca haga ajustes en la máquina mientras esté operando.



ADVERTENCIA: *Un chorro de alta presión puede ocasionar que trozos de pintura y otras partículas vuelen a altas velocidades por el aire.*

10. Elementos de seguridad para la protección de los ojos y los pies deben ser usados con este equipo.
11. Unidades con pistola de apagado no deben ser operadas con la pistola en la posición apagada por largos períodos de tiempo pues ésto puede causar daños a la bomba.
12. El mejor seguro contra un accidente es la precaución y el conocimiento de la máquina.
13. Landa no se hará responsable de ninguno de los cambios hechos a nuestras unidades estándar, o por ningún componente que no sea comprado directamente a Landa.



ADVERTENCIA: *Mantenga el chorro de agua lejos de cables eléctricos para prevenir graves choques eléctricos.*

14. Lea las instrucciones de seguridad proporcionadas para el motor.
15. Nunca opere la bomba en vacío o deje la pistola cerrada más de 5 minutos.
16. No permita que los niños operen la lavadora a presión en ningún momento.
17. Para prevenir una herida grave asegúrese que el conector rápido de la manguera de descarga este bien ajustado antes de usar la máquina lavadora a presión.
18. No permita que ácidos o fluidos abrasivos pasen a través de la bomba hidráulica.
19. No opere esta máquina estando fatigado o bajo la influencia del alcohol o drogas. Mantenga el área de operación lejos de las personas.
20. El agua de entrada deberá ser fría.
21. No se sobreestire o pare en soportes inestables, mantenga el balance y pie firme en todo momento.

22. Siga las instrucciones de mantenimiento especificados en el manual.
23. Siempre desconecte la máquina cuando realice reparaciones a la misma.
24. Apague el quemador y libere de presión la pistola y manguera de aspersión. Enfríe el serpentín a 100°F antes de apagar la máquina.

PRECAUCION: *Asegúrese que el quemador esté apagado y que el gatillo de la pistola de aspersión este cerrado.*

VERIFICACION ANTES DE OPERACION

- Aceite para bomba (aceite SAE 30W sin detergente, general)
- Suministro de agua fría (6 gpm • 5/8" • 20 psi)
- Manguera, varilla, boquilla (tamaño de boquilla según placa de serie)
- Filtro de agua (intacto, no restrictivo)

PROCEDIMIENTOS DE INSTALACION

Este equipo es para uso en interior. Este equipo debe ser guardado bajo techo cuando no esta en operacion.

1. Conecte una manguera de jardin de 5/8" al conector de entrada. El flujo mínimo debe ser de 5 gpm.
2. Conecte una manguera de alta presión a la boquilla de descarga usando una conexion rápida. Asegure el conector ajustándolo en su lugar tirando el collar del enganche trasero hacia atrás e insertándolo en la boquilla de descarga y empujando el collar después hacia adelante para asegurarlo en su lugar.
3. Conecte la varilla a la pistola de riego usando cinta de teflón en la rosca para prevenir fugas.
4. Conecte el conector giratorio (swivel) en la manguera de descarga a la pistola de riego usando cinta de teflon en la rosca.
5. Remueva el tapón del aceite de encima de la bomba de la lavadora a presión y reemplácelo con el medidor de nivel (dipstick) proporcionado.
6. Verifique el nivel del aceite en el vidrio de observación que está al lado de la bomba. El aceite debe ser visible hasta la mitad del vidrio de observación (30W no-detergente).
7. Esta unidad cuando esté instalada deberá de estar eléctricamente conectada a tierra y en concordancia con las reglas locales de servicio público.

INSTRUCCIONES DE ENCENDIDO Y OPERACION

1. ¡ALTO! Lea el manual de operación antes de operar ésta máquina. Omisión de leer el instructivo de seguridad y operación pueda resultar en lesión personal o daño a la propiedad.
2. Conecte la manguera del suministro de agua al conector de entrada y abra la llave de paso.
3. Revise los niveles de aceite y combustible.
4. Conecte la manguera de alta presión al niple de descarga deslizado el acople rápido hacia atrás (si se va a utilizar algún detergente, instale - el inyector apropiado para detergentes como se muestra en la página E).
5. Inserte el cople rápido al niple de descarga y asegúrelo empujando el collar del conector rápido hacia adelante.
6. Instale firmemente la boquilla de alta presión que desee a la varilla de aspersion como se describe en los pasos 4 y 5.
7. Conecte el cable eléctrico a la fuente de poder apropiado y oprima el - botón de encendido del cable eléctrico GFCI.
8. Sujete firmemente la varilla de aspersion y abra la válvula de presión en sentido inverso a las manecillas del reloj.
9. Oprima el switch en posición de la bomba hidráulica cuando obtenga un flujo continuo de agua por la varilla de aspersion. La unidad se encuentra lista para utilizar agua fría para limpieza al abrir la válvula de presión en sentido de las manecillas de reloj para alcanzar la presión deseada.
10. Para utilizar agua caliente oprima el switch en posición del quemador. (El quemador se encenderá automáticamente).

TECNICAS GENERALES DE LAVADO

1. Sostenga la boquilla de riego aproximadamente a 30 cm de la superficie a lavar. Riegue a cierto ángulo a modo que golpee debajo de la suciedad o materia y la desprenda.
2. Cuando esté lavando objetos grandes, use un inyector detergente opcional para aplicar el detergente. Empiece el lavado de abajo hacia arriba. Se ahorrará detergente y obtendrá resultados más rápidos si permite que el detergente se asiente de 5 a 10 minutos. Después de lavar, enjuague de arriba hacia abajo.
3. Para la limpieza de mugre o materia pesada se recomienda un fuerte chorro de agua limpia antes de usar el agente limpiador.

ADVERTENCIA: *Con la maquina apagada, aabra la pistola para dejar salir la presión antes de remover la manguera de descarga.*



GARANTÍA DE LANDA PARA SUS PRODUCTOS EQUIPOS DE LAVADO A PRESIÓN

QUÉ CUBRE ESTA GARANTÍA

LANDA, INC. garantiza al primer comprador que todos los equipos LANDA de lavado a presión están libres de defectos de materiales y de fabricación durante el uso normal de la unidad y durante el tiempo que se indica más abajo. Esta Garantía Limitada está sujeta a las exclusiones que se muestran a continuación. Dicha garantía entra en vigencia a partir de la fecha de la compra del equipo y se aplica únicamente a los componentes originales. Cualquier parte que se reemplace durante el período cubierto por esta garantía estará comprendida en el período de garantía restante para dicha parte.

GARANTÍA DE CINCO AÑOS PARA LAS PARTES Y DE UN AÑO PARA LA MANO DE OBRA:

Esta garantía cubre los componentes fabricados por Landa, como por ejemplo bastidores, manijas, envoltura de bobinas, tanques con flotador, tanques para combustible, cubiertas de correas y bobinas. Los componentes internos relacionados con el aceite de las bombas una garantía de 5 años.

GARANTÍA DE UN AÑO MÍNIMO PARA LAS PARTES Y DE UN AÑO PARA LA MANO DE OBRA:

El resto de los componentes, sin incluir el desgaste normal de los artículos que se describen abajo, estará cubierto por el período que especifique su fabricante original, con un año como mínimo. La garantía para la mano de obra que se aplica a estas partes será de un año, sin perjuicio de la duración de la garantía del fabricante del componente original.

GARANTÍA SUMINISTRADA POR OTROS FABRICANTES:

Los motores, generadores y máquinas están cubiertos por la garantía de sus fabricantes. Los centros de servicios locales autorizados por sus fabricantes prestan el servicio de mantenimiento y reparación de dichas unidades. LANDA no puede proporcionar garantía alguna para estos artículos.

REPUESTOS NO CUBIERTOS POR LA GARANTÍA:

Estas partes, sin incluir el desgaste normal de los artículos que se describen abajo, estarán cubiertas por el período que especifique su fabricante original. Estas partes no están cubiertas por la garantía de mano de obra.

ESTA GARANTÍA NO CUBRE:

Esta garantía no cubre los siguientes artículos:

1. Artículos que tienen un desgaste normal, como ser boquillas, pistolas, mangueras de descarga, extensiones, acopladores de conexión rápida, sellos, filtros, juntas, anillos en "O", empaquetados, pistones, montaje de válvulas, filtros de malla, correas, cepillos, etc.
2. Daño o malfuncionamiento debido a accidentes, abuso, modificaciones, alteraciones, instalación inapropiada, servicio inapropiado, incumplimiento de las instrucciones de mantenimiento del fabricante o uso del equipo con otros fines que no se adhieran a las especificaciones contenidas en el Manual del operador.
3. Daño a causa de heladas, deterioro debido a productos químicos, acumulación de escamas, oxidación, corrosión o expansión térmica.
4. Daño a los componentes debido a fluctuaciones en el suministro eléctrico o al abastecimiento de agua.
5. Servicio de mantenimiento normal, incluso los ajustes, limpieza del sistema de combustible y de obstrucciones.
6. Transporte al centro de servicios, cargos por mano de obra en planta o daño ocurrido durante el flete.
7. El trabajo de mano de obra se excluye especialmente para todas las máquinas que se utilizan como equipos de alquiler.

QUÉ DEBE HACER PARA OBTENER EL SERVICIO DE LA GARANTÍA

A pesar de no ser necesario para el servicio de garantía, le solicitamos que registre su unidad para el lavado a presión. Para ello, llene la tarjeta de registro y envíela a vuelta de correo. Para obtener el servicio de LANDA de la garantía, debe hacer llegar el producto a un Distribuidor de LANDA autorizado, con flete prepago, acompañado del comprobante de la compra, dentro del período prescrito por la garantía. En caso de que el producto esté instalado de forma permanente, deberá notificar el defecto a su Distribuidor Autorizado de LANDA. El distribuidor Autorizado de LANDA presentará un reclamo a Landa la cual deberá verificar el defecto. En la mayoría de los casos, deberá enviar la parte a LANDA con flete prepago junto con el reclamo. Para el servicio de la garantía de los componentes garantizados por otros fabricantes, su Distribuidor Autorizado de LANDA le ayudará a obtener el servicio que necesite de estos fabricantes por medio de sus centros locales de servicio autorizado.

LIMITACIÓN DE LA RESPONSABILIDAD

LANDA específicamente renuncia a la responsabilidad de todo daño y perjuicio especial, incidental, o consecuencial. La responsabilidad de LANDA con respecto a todo reclamo de cualquier índole, no superará, bajo circunstancia alguna, el precio de compra del producto en cuestión. LANDA ha puesto todo su empeño para asegurarse de que las ilustraciones y especificaciones son las que corresponden; no obstante, estas no implican la garantía de comerciabilidad o de aptitud para un fin en particular o que el producto sea un fiel reflejo de las ilustraciones y especificaciones. **LA GARANTÍA CONTENIDA EN LA PRESENTE REEMPLAZA A CUALQUIER OTRA GARANTÍA, SEA EXPRESA, IMPLÍCITA, INCLUSO TODA GARANTÍA IMPLÍCITA DE APTITUD PARA UN FIN EN PARTICULAR. LANDA no autoriza a terceros, incluso a los Distribuidores Autorizados de LANDA, a efectuar manifestación o promesa alguna en nombre de LANDA ni a modificar los términos, condiciones o limitaciones en modo alguno. Es responsabilidad del Comprador asegurarse de que la instalación y el uso de los productos LANDA se realice de acuerdo con los códigos locales. Bien que Landa intenta asegurarse de que sus productos cumplan con los códigos nacionales, no se responsabiliza por el procedimiento de utilización del producto ni por su instalación por parte del Comprador.**

LANDA INC.

1-360-833-9100 • 1-800-547-8672 • www.landa.com



Form #96-602 • Revised 2/04 • Printed in U.S.A. by Landa, Inc.